

# HOW TO?

## Goodwill Hangers

### What is it used for?

Goodwill Hangers are used to hang your portraits on the wall.

### How do I use the goodwill hangers?

Hanging portraits on the wall is different for everyone. Some people only hang items on the way if they can secure the "artwork" in the stud. Other people have no problem just placing a nail in the drywall. This is a decision you have to make for yourself (and your customer). Be careful if you decide to place a nail in drywall without using toggle bolts (or the similar plastic product).

Select the area on your wall where you plan to hang your "artwork." Slip the nail provided in the holes in the hanger. Hammer the nail (through the holes in the hanger) into the wall. Be sure to measure from the top of the ceiling as well as from the sides to be sure that your frame will fit your space.

Place the wire on the back of your frame in the slant on the goodwill hanger.

### When should I use the 30lb, 50lb or 100lb hanger?

The weight listed is the recommend "up to" weight for the hanger. Use the 30lb hanger on framed images 11x14 and smaller. Use the 50lb hanger on framed images 16x20 and 20x24. Use the 100lb hanger on framed images larger than 20x24.

This is not an absolute guide. Pick up your frame and get a feel for how heavy it is. Glass adds to the weight. Your image adds to the weight. Depending on the overall weight and size, you may need to use a larger size or even use two goodwill hangers to balance the weight and protect your wall.